

ITTING INSTRUCTION 1. PEEL OFF BACK PAPER



Begin by removing the protective back from the adhesive surface and proceed to slice a 5 cm gap down the center of the paper.

4. PEEL OFF BACK PAPER



Remove the back paper gradually toward the front, leaving around 10 cm exposed.

7. PRESS THE STICKER



Peel off the back paper on the top of the panel

10. HEAT UP THE STICKER



Gently apply pressure on the sticker using your finger and move it towards the back until you reach the edge. It's best to begin from the crease and work your way outwards.

SET THE POSITION



Set the position of stickers on the shroud's front and back corners

5. PRESS THE STICKER



Gently apply pressure to the sticker using your finger, gradually moving towards the front until you reach the edge

8. PEEL OFF BACK PAPER



Press the sticker gently and gradually to ensure it adheres completely to the upper panels edge.

11. PRESS THE STICKER



Remove the remaining back paper from the sticker. Use your fingers to firmly press the sticker onto the panel, starting from the back and working towards the front edge.

3. STICK THE GRAPHIC



Affix the sticker onto the area where it was previously trimmed.

6. HEAT UP THE STICKER



Apply heat from a hair dryer to the lower section of the sticker. As the sticker becomes more pliable, press it firmly onto the surface, working your way towards the edge in a slow and deliberate manner.

9. FOLD OVER THE EDGE



Remove the back paper and apply heat to activate the adhesive of the sticker.

12. LET THE ADHESIVE BOND



To ensure optimal adhesion, allow the plastic to sit at room temperature for a full 24-hour period. The following day, carefully inspect the edges and gently apply pressure to any areas where the sticker may have become detached.









Ľudovíta Stárka 16 911 05 Trenčín Slovakia

+421 32 6423 395 info@scrubdesignz.com www.scrubdesignz.com